

**APPLICATION FOR
UNITED STATES PATENT
IN THE NAME OF**

**Mark L. Burgener
Dylan Kelly
James Cable**

OF

PEREGRINE SEMICONDUCTOR

FOR

LOW NOISE CHARGE PUMP METHOD AND APPARATUS

**DOCKET NO. PER-005-PAP
(Client Ref. Pere-041)**

Prepared by
William Boling

Jaquez & Associates

Express Mail No. EK694133438US

LOW NOISE CHARGE PUMP METHOD AND APPARATUS

BACKGROUND OF THE INVENTION

1. *Field of the Invention*

5 [001] This invention generally relates to electronic power supplies, and more specifically to capacitive energy transfer DC-to-DC converters (DC/DC converters), such as charge pumps.

2. *Related Art*

10 [002] DC/DC converter power supply circuits provide a DC output voltage based upon a DC source voltage. The output is typically at a different voltage than the input. As the term is used herein, DC/DC converters do not encompass voltage reduction regulator circuits that use a linear pass device, but rather involve energy transfer from input to output through an energy storage device, such as a capacitor or an inductor.

15 [003] The DC/DC converters of interest herein are charge pumps, which obtain energy for the output voltage primarily by means of capacitive transfer from the source to the output. An inductor is not generally the primary energy transfer device in a charge pump, though of course hybrid devices are possible that employ inductive energy transfer in addition to capacitive energy transfer. A charge pump may derive an output voltage that is higher than a source voltage, or that is inverted from a source voltage, or that is referenced to a different voltage than the source voltage, and indeed may do all of these things concurrently.

20 [004] Charge pumps may be implemented for a wide variety of purposes. They are well suited for integrated circuit fabrication because the devices and elements required are compatible with most integrated circuit fabrication techniques. For example, a charge pump may be employed to generate a negative gate bias supply for an integrated circuit that switches an antenna between send and receive circuitry of a transceiver, as shown in FIGURE 1. Many wireless transceivers, such as cellular
25 telephones, employ a single antenna for both receiving and transmitting. While such systems are receiving, an antenna 102 must be coupled to receive circuitry that may include, for example, a filter 104 and a low noise amplifier 106, to provide the received signal for further processing. However, while such systems are transmitting, the antenna 102 must be disconnected from the sensitive receive circuitry and coupled instead to relatively high power transmit circuitry. The transmit circuitry may include, for
30 example, a power amplifier 108 and a transmit filter 110 to process a transmit signal.

[005] A RF switch 112 may be used to perform such antenna switching functions. Ideally, such switches may be integrated together with the receive and/or transmit circuitry, and in any event are desirably very small, due to space limitations in portable transceivers such as mobile telephones and handy talkies. In order to achieve good performance from switching devices, such as MOSFETs, used to implement such RF switches, many designs need a special bias supply that extends negatively below the supply rails of the transmit and receive circuitry, such as a -3V supply. In view of the space and cost constraints of transceiver units such as mobile telephones, a charge pump is particularly suitable for generating such a bias supply, because it can be readily integrated into a very small circuit.

[006] The RF switch 112 conveys relatively high power signals to the antenna 102 during transmission. However, during receive, the signal passed by the RF switch 112 may be measured in tens of nanovolts. Sharp noise transitions may have an extremely broad Fourier frequency content, and thus even signals at amplitudes on the order of millivolts may interfere unacceptably with reception if the signals have extremely fast edges. While the filter 104 can remove some noise, it is important that the RF switch 112 not introduce noise, particularly noise having components near the center frequency of the received signal. Thus, the receive/transmit switch of FIGURE 1 illustrates one of many circumstances in which a charge pump may be desired for a circuit that nonetheless requires extremely low noise.

[007] Unfortunately, noise generation is one of the most common drawbacks of charge pumps. Current spikes are typically coupled into both input and output supplies, together with voltage ripples and spikes. When a charge pump is integrated together with other devices, such electronic noise may be coupled throughout the circuitry of the integrated device by a variety of mechanisms that are difficult to control. Thus, a need exists for charge pumps that avoid generating excessive noise, so as to reduce charge pump noise injection into source supplies, output supplies, and related circuits.

[008] The method and apparatus presented herein address this need for a low-noise charge pump. Various aspects of the method and apparatus described herein will be seen to provide further advantages, as well, for the design and construction of charge pumps that are relatively free of noise spurs.

SUMMARY

[009] A charge pump method and apparatus for DC-to-DC conversion is set forth by which an output is generated by alternately coupling a transfer capacitor to an input supply and then to the output. A charge pump clock output is generated to control a transfer capacitor coupling switch in a charge pump circuit. The charge pump method (or apparatus) further includes a combination of one or more aspects of the method or apparatus, as set forth below, in order to reduce noise or otherwise improve the design.

[010] One aspect of the charge pump method described herein includes generating an output supply by transferring charge from a source voltage to a transfer capacitor ("TC") alternately with transferring charge from the TC to the output supply. A TC-coupling switch ("TCCS") circuit is a switch that couples the TC to a supply under control of a charge pump clock ("CPClk"). This method includes coupling the TC to the output supply during discharge periods via a discharging TCCS circuit, and actively limiting a rate of voltage change of the CPClk output during both positive and negative transitions.

[011] An aspect of the charge pump apparatus described herein may be employed to generate an output voltage supply within a circuit. This aspect includes a transfer capacitor ("TC") and a plurality of TC coupling switches ("TCCSs"), each TCCS controlled by a charge pump clock ("CPClk") output. The apparatus also has a CPClk generation circuit, which includes circuitry that limits a rate of rise of the CPClk output and circuitry that limits a rate of fall of the CPClk output. The TCCSs are coupled to the TC, and are controlled to couple the TC to a voltage source during periodic first periods, and to couple the TC to the output voltage during periodic second periods that are not concurrent with the first periods.

[012] Another aspect of the charge pump apparatus described herein may be also be used for generating an output voltage supply within a circuit. This aspect includes a transfer capacitor ("TC") coupled alternately between source connections and output connections, and a plurality of active switches that are each switchable under control of a charge pump clock ("CPClk") output to conduct, or not. This aspect includes a CPClk generating circuit that has an active driver circuit configured to source current to, and sink current from, a driver output node, together with circuitry to limit the source current, and circuitry to limit the sink current, of the active driver circuit.

[013] Another aspect of the charge pump described herein is a method of alternately transferring charge from a source voltage to a transfer capacitor ("TC"), and from the TC to an output supply, to generate an output supply. The method includes coupling the TC to the output supply via a discharging switch under control of a charge pump clock ("CPClk") output. The method also includes

limiting source and sink currents between a driver circuit and a corresponding output node, within a generator circuit of the CPClk.

[014] Yet another aspect of the charge pump method described herein alternately transfers charge from a source voltage to a transfer capacitor ("TC"), and from the TC to an output supply. This method includes coupling the TC to the output supply during discharge periods via a discharging switch circuit under control of a single phase charge pump clock ("CPClk") output, and coupling the TC to the voltage source via a charging switch circuit under control of the single phase CPClk output.

[015] A related aspect of the charge pump apparatus described herein may be used for generating an output voltage supply. This apparatus includes a transfer capacitor ("TC"), one or more source switching devices in series between the TC and the source voltage, and one or more output switching devices in series between the TC and the output supply. A single phase output of a charge pump clock ("CPClk") generating circuit is coupled to all of the source switching devices to cause them to conduct only during charge periods, and is also coupled to all of the output switching devices to cause them to conduct only during discharge periods, wherein the charge and discharge periods alternate and do not overlap.

[016] A further aspect of the charge pump method described herein may generate an output supply by alternately transferring charge from a source voltage to a transfer capacitor ("TC"), and from the TC to the output supply. This method includes coupling a first charge pump clock ("CPClk") output to a TC charging switch control node via a first capacitive coupling network, and coupling the TC to the source voltage during charge periods under control of the first CPClk output. The method also includes coupling a second CPClk output to a TC discharging switch control node via a second capacitive coupling network, and coupling the TC to the output supply during discharge periods that nonconcurrently alternate with the charge periods, under control of the second CPClk output.

[017] A further aspect of the charge pump apparatus described herein may be used for generating an output voltage supply, and includes a transfer capacitor ("TC"). This apparatus includes one or more source switching devices, having a corresponding control node, disposed in series between the TC and a source supply, and also includes one or more output switching devices, having corresponding control nodes, disposed in series between the TC and the output supply. This apparatus also includes a capacitive coupling circuit coupling a charge pump clock output to the control node of a source switching device or to the control node of an output switching device.

[018] Yet a further method aspect of the charge pump described herein includes steps of disposing an output hot switch between a transfer capacitor ("TC") node and a charge pump output, and disposing an output common switch between the opposite TC node and a common connection of the charge pump output. This method also includes establishing a higher control node AC impedance for the hot switch, as compared to a control node AC impedance for the output common switch. A related aspect provides apparatus generally corresponding to this method.

[019] Embodiments of the charge pump method or apparatus may employ any combination of individual aspects of the method or apparatus, and may be configured in a wide range of charge pump architectures and configurations.

BRIEF DESCRIPTION OF THE DRAWINGS

[020] Embodiments of the present invention will be more readily understood by reference to the following figures, in which like reference numbers and designations indicate like elements.

[021] FIGURE 1 is a block diagram illustrating use of a RF switch.

5 [022] FIGURE 2 is a block diagram illustrating basic charge pump operations.

[023] FIGURE 3 is a charge pump schematic diagram illustrating some of the current paths in which noise may be reduced by employing aspects of the method and apparatus described herein.

[024] FIGURE 4 is a schematic diagram of exemplary current-limited inverters.

[025] FIGURE 5 is a schematic diagram of a current-starved oscillator for a charge pump.

10 [026] FIGURE 6 is a schematic diagram of a charge pump in which the active switches are coupled to control signals by means of capacitive coupling.

[027] FIGURE 7 is a schematic diagram of a charge pump employing passive switches.

[028] FIGURE 8 is a schematic diagram of charge pump switches having a control node capacitively coupled to a charge pump clock output.

15 [029] FIGURE 9 is a block diagram illustrating alternative charge pump configurations.

[030] FIGURE 10 is a block schematic diagram illustrating techniques for using charge pumps to produce arbitrary output voltages.

DETAILED DESCRIPTION*Overview - Charge Pump Configurations*

[031] FIGURE 2 illustrates some basic charge pump operations. Filtering capacitors, typically present on each input and output supply, are omitted from FIGURE 2 to avoid confusion with an energy transfer capacitor C_T 202. When S1 204 and S2 206 are closed, C_T 202 is connected to the source DC supply connections V_{S+} 208 and V_{S-} 210, and thus C_T 202 is charged to the voltage V_S , having a value $[(V_{S+}) - (V_{S-})]$. S1 204 and S2 206 are then opened, permitting C_T 202 to float. Next, S3 212 and S4 214 are closed, causing the floating transfer capacitor C_T 202 to "fly" to the output supply (for which reason such capacitors are also called fly capacitors). The charged C_T is thus connected to output supply connections V_{O1+} 216 and V_{O1-} 218 (output V_{O1}). Presuming that the voltage of output V_{O1} is smaller than the voltage stored on C_T 202, C_T 202 discharges, transferring energy to V_{O1} , which may be an output supply.

[032] Many different output configurations are possible using just these four switches S1 204, S2 206, S3 212 and S4 214, together with the transfer capacitor C_T 202. A first example is a voltage doubling configuration, wherein V_{O1-} 218 is connected to V_{S+} 208, causing V_{O1+} 216 to achieve a voltage roughly twice that of V_{S+} 208 (both with respect to V_{S-} 210, neglecting losses). A second example is a voltage inverting configuration, in which V_{O1+} 216 is connected to V_{S-} 210, such that V_{O1} will reach approximately $-V_S$ (with respect to V_{S-} 210). A third example is a supply isolating configuration, in which neither V_{O1+} 216 nor V_{O1-} 218 is tied through a fixed voltage connection to a source voltage connection. Rather, the input lines may be isolated from the output insofar as is permitted by the isolation capability of the switches S1 204 and S3 212, and of the switches S2 206 and S4 214.

[033] The skilled person will understand certain features without a need for explicit details. For example, because the transfer capacitor C_T 202 must be disconnected from the output while connecting to the input, maintaining a reasonably constant voltage on the output generally requires a storage device. Such storage device typically comprises a filter capacitor, which is not shown in FIGURE 2. As another example, current and voltage for the output may vary depending upon many factors. The skilled person may make allowance for such factors to anticipate a voltage of the output, or may choose to regulate the voltage of the output. Such regulation is not shown, but may, for example, comprise controlling the frequency of "pump" cycles during which C_T 202 is first charged to V_S and then discharged to voltage V_{O1} . Regulation may also comprise controlling a value of the voltage source for the charge pump, as described with respect to FIGURE 10 below.

[034] Additional output connection switches, such as S5 220 and S6 222, may enable a charge pump to provide other voltages, multiplexing the use of a single transfer or fly capacitor C_T 202. For example, charge and discharge cycles may alternate without overlapping. C_T may be charged to V_S during each charge cycle. However, during one discharge cycle, C_T may be discharged to V_{o2} (V_{o2+} 224 to V_{o2-} 226), while during another discharge cycle C_T is discharged to V_{o1} . In this manner, three voltages of roughly equal value may be created -- V_S , V_{o1} and V_{o2} . The connections made between these voltages determines whether the charge pump circuit functions as a voltage tripler, or as a double-voltage inverter, an isolated $2 \cdot V_S$ supply, two isolated outputs, etc. These principles may be extended to further output combinations.

[035] In typical implementations, each of the switches S1 204, S2 206, S3 212 and S4 214 (as well as other switches if used, such as S5 220 and S6 222) may comprise an appropriate transistor, such as a MOSFET. However, in many circumstances it is possible to substitute a simple diode for a switch, when the voltage and current flow requirements of the particular configuration of a specific charge pump circuit permit.

[036] The basic charge pump architecture illustrated in FIGURE 2 may also be replicated for operation in a "push-pull" fashion. For this purpose, a second C_T may be connected to V_S while the first C_T is connected to V_{o1} , and then such second C_T may be discharged to V_{o1} the first C_T is connected to V_S . Such techniques may provide more constant current capacity to the output supply, and may aid in reducing output voltage ripple. Thus, charge pump DC/DC converters may be designed in a wide range of configurations to provide many different outputs from a single DC supply.

Charge Pump Noise

[037] As noted above, noise is one of the most common problems associated with charge pumps. FIGURE 3 illustrates an exemplary charge pump architecture, showing some of the paths in which noise currents may typically occur. The charge pump of FIGURE 3 includes a transfer capacitor C_T 202, together with source supply connections V_{S+} 208 and V_{S-} 210, which are substantially as shown in FIGURE 2, and accordingly are identically numbered. FIGURE 3 also includes output supply connections V_{o+} 316 and V_{o-} 318. The fly capacitor coupling switches, which couple C_T 202 to the source supply V_S or to the output supply V_o , are shown as MOSFET devices controlled by a signal applied to a control node (the device gate). The fly capacitor coupling switches include a P-channel switch 304 under control of a first clock output 354, a P-channel switch 306 under control of a second clock output 356, an N-channel switch 312 under control of a third clock output 362, and an N-channel

switch 314 under control of a fourth clock output 364. The four charge pump clock outputs (354, 356, 362, and 364) are generated in a charge pump clock generator circuit 350. A filter capacitor 330 for the output supply V_o , as well as a current load 332 on V_o , are also shown.

[038] Four ammeters are represented to illustrate paths in which noise currents may occur.

5 From these paths, noise may be unintentionally coupled other circuits associated with the charge pump. For example, voltage noise may be coupled into other circuits through common supply connections, or via parasitic capacitive coupling, while current noise may be injected into other circuits through inductive coupling, or via a shared impedance. A source loading ammeter 342 is disposed between the source supply V_{s+} 208 and the switch 304, and an output charging ammeter 344 is disposed between the switch
10 312 and the output filter capacitor 330. Clock generator ammeters are disposed between the clock generator 350 and its supply source, with ammeter 346 between V_{s+} 208 and clock generator 350, and ammeter 348 between the clock generator 350 and V_{s-} 210. The explanation of charge pump noise currents, which is set forth below with reference to these four ammeters, is representative in nature, and is not intended to be comprehensive.

15 [039] In FIGURE 3, a charging period begins at the moment when both the switches 304 and 306 are closed, such that the C_T 202 is connected across the source supply and the ammeter 342 registers the charging current for C_T 202. An amplitude of a spike in the charging current is passively limited by the source impedance of the supply V_s and the parasitic resistance of C_T 202 itself, as well as by the difference between V_s and the voltage on the C_T 202. The spike amplitude may also be limited by active
20 control of conduction by the switches 304 and 306. In addition to controlling peak amplitude, a rate of rise of the charging current, di/dt , may be limited by limiting the speed with which the switches 304 and 306 are turned on.

[040] At the end of the charging period, the switches 304 and 306 will be turned off. A change in current will register in the ammeter 342 if C_T 202 is not fully charged at this time, with a di/dt slope
25 that depends in part upon the speed with which the series combination of switches 304 and 306 is turned off. Because the first clock output 354 and the second clock output 356 are coupled to corresponding control nodes of switches 304 and 306, respectively, the outputs 354 and 356 will be driven up to a voltage greater than their threshold voltages, which will induce a nonconducting off state in these switches. To drive up the voltage of the control nodes, these clock outputs source current to drive the
30 gate capacitance (and/or other parasitic capacitances and impedances) of the corresponding switch. The drive current will register in the ammeter 346. Due to the parasitic capacitances, a high dv/dt gate drive will typically cause a significant capacitive current spike in the corresponding ammeter 346.

[041] After the switches 304 and 306 are off, a discharge period may ensue that does not overlap the charge period. To begin the discharge period, the third clock 362 and the fourth clock 364 will raise voltages of control nodes of the switches 314 and 312, respectively, above a V_{gs} threshold voltage to turn each switch on to a conducting state. The resulting capacitive gate current of the switches 312 and 314 will register in the ammeter 346, with a peak value and di/dt that depend in part upon dv/dt of the clock output. In order to minimize power dissipation in the switches, the clock edges in such circuits have typically been made rather fast.

[042] As the later of switches 312 and 314 turns on, C_T 202 begins discharging into C_o 330 with a current that will register in the ammeter 344. At the end of the discharge clock period, the third clock output 362 and the fourth clock output 364 sink current to drive down to an off voltage, causing gate currents, to discharge the gate capacitance of the corresponding switches, that will register in ammeter 348. Finally, C_T 202 is disconnected from C_o 330, which may cause another current step to register in the ammeter 344 if discharging of C_T 202 has not been completed.

[043] All switches remain off until the clock outputs 354 and 356 sink current from the gates of switches 304 and 306, respectively, to reduce the control node voltage of those switches to a level that is negatively greater than their V_{gs} thresholds, thereby causing the switches to turn on and begin the charging period. The sink current provided by the clock outputs 354 and 356 to effect this change will register in the ammeter 348. A di/dt of such current depends substantially upon a magnitude of the dv/dt at which these clock outputs transition negatively.

[044] Each high di/dt current spike described above is likely to be coupled into nearby circuitry, whether through mutual inductances, common impedances, or common connections. Reducing some or all of the identified noise sources may be desirable for circuits, such as that described with respect to FIGURE 1, which need a charge pump DC/DC converter but also require very low noise. Various features of the following figure, taken in combinations, may be employed to construct such a desirable charge pump. Other benefits will also become apparent, such as the convenience and simplicity of control by a single-phase clock.

Quiet Inverting Charge Pump

[045] FIGURES 4, 5 and 6 illustrate an exemplary quiet, inverting embodiment of a charge pump. FIGURE 4 illustrates exemplary circuitry for establishing current-limited drive circuits (here, inverters), which may be used within a charge pump clock generating circuit. FIGURE 5 illustrates an exemplary charge pump clock generating circuit that utilizes current-limited, inverting drive circuits

configured to form a current-starved ring oscillator. FIGURE 6 illustrates using a single charge pump clock output to drive all of the active fly capacitor coupling switches in an exemplary charge pump. Throughout the descriptions that are set forth below, size references for some exemplary FET devices are indicated parenthetically as a channel width (W) and length (L), in micron units. These size references are appropriate for a low voltage silicon-on-insulator ("SOI") integrated circuit, and are useful for relative size considerations. In an exemplary embodiment, threshold voltages for P-channel MOSFETs are -0.25 V, and for N-channel MOSFETs are +0.5 V. Device sizes, threshold voltages, and other considerations may, of course, be adjusted as appropriate for varying designs and processes, and indeed alternatives to MOSFETS, such as BJTs or other amplifying/switching devices, may be used with appropriate adaptation.

[046] FIGURE 4 is a schematic diagram of a current limited, inverting drive circuit. An input voltage supply is connected via Vin+ 402 and common connection 404. A reference current, limited by a resistor 406, is established through diode-connected MOSFETs 408 (W 7.5, L 2) and 410 (W 7.5, L 4) to create a P-gate reference voltage 412 and an N-gate reference voltage 414. The drive circuit 416 has an input node 418 and an output node 420, and is formed by connecting a P-channel FET 422 (W 5, L 0.8) in series with an N-channel FET 424 (W 2, L 0.8), as shown. The drive circuit 416 drives current to the output node 420, sourcing or sinking current to raise or lower the voltage of the output node. Circuitry is provided that limits the current drive capability of the drive circuit 416, as compared to an absence of such devices. "Absence" of a series device should be understood to mean replacement by a direct connection, while "absence" of a parallel device should be understood to mean merely omission of such device.

[047] The current source capability of the driver circuit 416 is limited through a source current limit circuit 426, which may, for example, comprise a P-channel FET 428 (W 1.5, L 2). The FET 428 may be gate-coupled to the P-gate reference 412 as a current mirror that limits current, for example, to 1 μ A or less. The current sink capability of the driver circuit 416 may be similarly limited by a sink current limit circuit 430, comprised for example of an N-channel FET 432 (W 1.5, L 4) coupled to the N-gate reference 414 as a current mirror (e.g. limited to 1 μ A). Establishing 1 μ A current limits in FETs 428 and 432 may require about 5 μ A through reference current FETs 408 and 410, due to the 1:5 size ratio of the exemplary corresponding devices. Equal magnitudes for source and sink current limits may reduce undesirable harmonic generation. Any other appropriate techniques for creating current limited drive circuits may be employed in the alternative, such as using low-conductivity FETs or resistors, etc., to restrain either or both of the source and sink drive capability of such drive circuit.

[048] Additional circuitry, shown connected by phantom lines to the P-gate and N-gate references 412 and 414, represents optional additional current-limited inverter circuits that may be coupled to the same current reference voltages 412 and 414.

[049] FIGURE 5 is a schematic diagram of a ring oscillator 500, which will be referred to as a "current-starved" ring oscillator operating with an exemplary period of 1 μ S. Inverters 502, 504 and 506 may be equivalent to the inverter 416 as shown in FIGURE 4. Each limits current from a source supply connection V_{in+} 402 by means of a source current limit 508, 510 and 512, respectively, which may be equivalent to the source current limit 426 shown in FIGURE 4. Each inverter also limits current from a sink supply connection common reference 404 by means of a sink current limit 514, 516 or 518, respectively, each of which may be equivalent to the sink current limit 430 of FIGURE 4. Output transition rates (dv/dt) for the inverting drive circuit 502 are actively limited by a capacitor 520 (*e.g.*, 90 ff) coupled to its output node, in conjunction with the "current starving" effect of the source and sink current limits 508 and 514, respectively. Similarly, dv/dt of the output node of the inverting drive circuit 504 is also actively limited by a capacitor 522 (*e.g.*, 90 ff) coupled thereto, in conjunction with the current drive limit devices 510 and 516 of the inverting drive circuit 504.

[050] Output transition dv/dt of CLK output 524 of the driver circuit 506 is actively limited by the source and sink current limits 512 and 518, in conjunction with the combined distributed capacitance of each driven device, which is represented by phantom capacitor 526. A discrete capacitor may, of course, be added if appropriate. The devices that constrain dv/dt on the input node of driver circuit 506 also limit dv/dt of the CLK output 524. Series connection of the three inverting driver circuits 502, 504, and 506, creates a ring oscillator. The current-starved ring oscillator 500 is an example of a charge pump clock generating circuit that includes circuits to reduce switching speeds of substantially all driver circuits within the clock generator. The current-starved ring oscillator 500 is also an exemplary circuit for producing a charge pump clock output 524 for which dv/dt is actively limited in both negative and positive transitions. Voltage of the CLK output 524 may oscillate substantially rail-to-rail (*e.g.*, between 0 to V_{in+}) with low dv/dt transitions, and may have a significantly sine-like shape.

[051] FIGURE 6 is a schematic diagram of a charge pump that may employ a single phase of a limited dv/dt clock, such as the output CLK 524 of the clock generator 500 shown in FIGURE 5. In an exemplary embodiment, V_{in+} is +3V with respect to ground (common reference), while V_{o-} is -3V. P-channel MOSFETs 602 and 604 (W 20, L 0.8) conduct during a charge phase, connecting a fly capacitor 606 (*e.g.*, 10 pf) to the source supply via connections V_{in+} 402 and common reference 404. At a later time, during a discharge period, the FETs 602 and 604 will be off (nonconducting), and N-channel FETs

608 (W 20, L 0.8) and 610 (W 5, L 0.8) will conduct, connecting the fly capacitor 606 between a common reference plus side, and an intermediate output stored on a storage capacitor 614.

[052] During this discharge period, the N-channel FET 608 couples one terminal of the fly capacitor 606 to a common reference (404) connection of the output supply. Concurrently, the N-channel FET 610 couples the opposite terminal of the fly capacitor 606 to the connection of the output supply (the junction of FET 610 and capacitor 614) that is opposite to the common reference connection of the output supply. The area of the device 610 is made much smaller (*e.g.*, half as large, or less -- one fourth as large in the exemplary embodiment) than the area of the device 608. The smaller size helps to reduce noise injection into the output, for example by minimizing coupling of control signals through the gate capacitance of the FET 610. For a typical FET, the device area is simply the length times the width. If other processing parameters are constant, a control node AC impedance (to conducting control signals into the switch) will vary approximately inversely with such area. However, control signal AC coupling impedance may be increased in other ways, for example by reducing the parasitic gate-body capacitance through increases in the dielectric thickness or reduction in the dielectric constant. Thus, the device 610 may be configured in various ways to have at least twice the control node AC impedance of the device 608.

[053] The voltage on storage capacitor 614 is filtered, by means of a resistor 616 and filter capacitor 618, to provide a filtered output supply voltage V_o with respect to common reference 404. The exemplary embodiment provides a quiet output but relatively low current capacity. The skilled person will readily adjust the current capacity of a circuit such as that of FIGURE 6, for example by employing small (to zero) values for the resistor 616, or by replacing resistor 616 with a primarily inductive impedance. Larger devices may also be employed for any or all of FETs 602, 604, 608 and 610, as well as a larger fly capacitor 606.

[054] Each of the FETs 602, 604, 608 and 610 is an example of an actively controllable transfer capacitor coupling switch ("TCCS"). First, each is disposed in series to couple a node of the transfer capacitor to the source supply (for charging switches) or to the output supply (for discharging switches). Second, the conductivity of each is actively controllable, under control of a signal applied to a control node of the switch (here, the gate of the FET). Such a control node has a significant impedance to primary conducting connections (here, the source and drain connections).

[055] As shown in FIGURE 6, the gate (control node) of each TCCS 602, 604, 608 and 610 may be capacitively coupled to the appropriate clock signal by means of a corresponding coupling

capacitor in conjunction with a bias resistor. Direct coupling could be employed by use of appropriate level shifting and isolation considerations. For the FETs 602, 604 and 608, capacitive coupling is effected by means of capacitors (*e.g.*, 1 pf) 618, 620 and 622, respectively, together with resistors (*e.g.*, 10 M Ω) 626, 628 and 630, respectively.

5 [056] In the case of a FET 610, the coupling is effected by two coupling circuits connected in series to reduce voltage stresses. Thus, a capacitor 636 (*e.g.*, 2 pf) couples the CLK 524 to an intermediate node where it is biased by a resistor 638 (*e.g.*, 10 M Ω) to an intermediate average voltage level (common reference voltage, in this case). From this intermediate node the charge pump clock output signal is coupled via a capacitor 624 (*e.g.*, 2 pf) to the gate of the FET 610, and biased by a resistor
10 632 (*e.g.*, 10 M Ω) to the source voltage of the FET. The modified capacitive coupling circuit for the FET 610 provides an example of a modified circuit that differs in some regard, but functions substantially equivalently, to another. Any circuit illustrated or described herein may be replaced (as needed) by such a modified circuit, if substantially the same function is performed. Extended voltage capacity circuits, such as series or cascode-coupled transistors or the series capacitors described above, and increased
15 current capacity circuits, such as parallel combinations of transistors, are examples of such equivalent circuits that may be employed, in place of any illustrated circuit, to satisfy particular design goals.

 [057] In the exemplary circuit, N-channel switches such as FETs 608 and 610 are switched on concurrently while P-channel switches such as FETs 602 and 604 are off, and the converse is also true. The gate threshold voltage of N-channel switches is positive (*e.g.*, conductive for $V_{gs} > 0.5V$), while the
20 gate threshold voltage of P-channel switches is negative (*e.g.*, conductive for $V_{gs} < -0.25V$). The active limitation of the dv/dt of transitions of CLK 524 therefore creates a period of time when all switches are off (*i.e.*, the duration of the transition from [average of CLK 524 - 0.25] to [average of CLK 524 + 0.5V]). Single-phase clock drive of a charge pump may be effected using different types of switches that have correspondingly different control voltage thresholds. However, bias voltages may need to be adjusted
25 accordingly to avoid simultaneous conduction of devices, such as FETs 602 and 608, that are disposed in series across a supply. The circuits and devices of FIGURE 6 provide a convenient approach for driving all actively controllable TCCSs of a charge pump from a single clock phase (*e.g.*, CLK 524), while ensuring that conduction periods for series fly capacitor coupling switches do not inadvertently overlap.

 [058] Each capacitive gate drive circuit shown in FIGURE 6 has a time constant τ which may
30 be expressed in terms of drive periods as $R \cdot C / (\text{clock drive period})$. In the exemplary circuit of FIGURE 6, τ is approximately 10 periods, because the switch drive signal CLK 524 has a period of about 1 μS . However, in many circumstances τ may be varied widely without unduly affecting operation of the

circuit. τ may be enlarged as much as desired, though this may adversely affect device area. In some circumstances, τ may also be reduced, and allowed to range for example down to 5 periods, to 2 periods, to 1 period, or even to 0.1 period or less without unduly impairing performance. Such reduction of τ may reduce the amplitude of the gate drive applied to the corresponding MOSFET, particularly if it is accomplished by reducing the size of the coupling capacitor (e.g., 618, 620, 622 or 624). This is due in part to capacitive voltage division between the coupling capacitor and the MOSFET gate capacitance. Such voltage division may reduce the magnitude of the control node voltage (V_{gs}), and hence may reduce conductivity of the switches when they are nominally enabled. Reducing τ may also reduce the proportion of time within each cycle during which the corresponding switch is turned on, which may in turn increase ripple voltages and/or load current capacity. The wide range from which τ may otherwise be chosen may be limited by such engineering considerations.

Alternative Charge Pump Embodiments

[059] Charge pumps are extremely versatile, and aspects of the charge pump method and apparatus herein may be employed in virtually any charge pump configuration. Some alternative techniques are set forth below, each of which may be implemented using aspects of the method and apparatus described herein.

[060] FIGURE 7 is a schematic diagram of a charge pump that generates a negative voltage V_o 710, and provides an example of using passive transfer capacitor coupling switches. A clock source CLK 524 is provided, which may be generated, for example, by the circuit of FIGURE 5. A transfer capacitor 702 charges via the clock source and via a passive switch 704 when CLK 524 is at a maximum value. When CLK 524 is at a minimum value, the transfer capacitor 702 discharges via the clock sink and a passive switch 706.

[061] Passive switch 704 may be an N-channel enhancement MOSFET connected drain to gate and having a low threshold voltage of about 0.5V, or may be a diode (anode to capacitor 702, cathode to ground), for example a low-voltage Schottky diode. Passive switch 706 may similarly be a diode-connected N-channel enhancement FET, or may be a discrete diode with anode to output capacitor 708, cathode to transfer capacitor 702. The dv/dt control of the drive CLK 524 effects quiet operation. However, there is some loss of efficiency and voltage output due to the non-zero forward conduction voltage of the devices 704 and 706. Thus, if CLK 524 is 3V p-p (e.g., oscillates between +3V and common), then V_o 710 may be only about -2.5V, even at light loads.

[062] Passive switches similar to devices 704 or 706 may be substituted in place of one or more active switches in many designs described herein, simplifying design but typically reducing output voltage. For example, in FIGURE 6, either or both of the active switches 604 and 610, together with their associated drive coupling circuitry, may be replaced by passive devices similar to devices 704 or 706.

5 Passive switches are controlled by a charge pump clock output, but not via a control node. Rather, connections to primary conduction nodes of such switches are driven, through circuit operation controlled by a charge pump clock output, to voltage levels at which the devices passively switch on or off.

[063] FIGURE 8 is a schematic diagram of an active p-switch 800 and of an active n-switch 830. Each is driven by a clock CLK 802. The p-switch 800, when "on," connects an external supply (e.g., $V+$ 804) to a fly capacitor for a charge pump, represented by C_p 806. The n-switch 830, when "on," connects a charge pump fly capacitor (or transfer capacitor), represented by C_p 814, to a supply connection such as $V-$ 816. The p-switch 800 couples CLK 802 to the gate of a P-channel MOSFET 808 via a coupling capacitor 812 and a bias resistor 810. With the bias resistor 810 connected to the source of the FET 808, it is preferable that the FET 808 has a small negative threshold voltage (e.g., $-0.25V$). For the n-switch 830, the gate of an N-channel MOSFET 818 is coupled to CLK 802 via a coupling capacitor 822, with a bias resistor 820 setting the average V_{gs} to zero volts. In this circumstance, it is preferred that the threshold voltage for the FET 818 has a small positive value (e.g., $0.5V$). Depending upon voltage levels, these switches 800 and 830 may employ series capacitive coupling circuits, and/or cascode or other extended-capability circuit equivalents. The effective τ of each capacitive coupling circuit may be set in accordance with the operating frequency of a charge pump in which it is used, ranging from 10 clock periods or more down to 0.1 clock periods or less, as described with respect to FIGURE 6. The τ of the capacitive coupling circuit within each n-switch and p-switch operating within a single charge pump under control of the same clock (e.g., CLK 524) may have substantially the same value. P-switches 800 and n-switches 830 may have different thresholds while operating from a common clock signal, provided that the bias voltage is set properly to ensure that a p-switch and an n-switch connected in series across a supply are precluded from concurrent conduction.

[064] FIGURE 9 is a block schematic diagram that illustrates "stacking" charge pump circuits to obtain higher or lower output voltages. Each switch 800 and 830 may be as illustrated in FIGURE 8, or as discussed in the text describing FIGURE 8. The circuit of FIGURE 9 may be configured as either a voltage tripler, or a voltage quadrupler, as follows: V_a 904 may be connected to a positive source voltage V_{s+} , and V_b 906 may be connected to a common reference voltage (ground). V_c 908 may also be coupled to V_{s+} . Operation of the n-switches and the p-switches connected to a transfer capacitor 902 will cause V_d 910 to be driven to $2 \cdot V_{s+}$. V_e 914 may be connected to V_d 910, and V_f 916 may be connected

to ground. With those connections, an output voltage V_h 920 will be driven to approximately $3 \cdot V_{s+}$ by means of fly capacitor 912 if V_g 918 is connected to V_{s+} . However, the output voltage V_h 920 will be driven to approximately $4 \cdot V_{s+}$ if V_g 918 is connected, instead, to V_d 910. A storage capacitor, though not shown, is generally provided somewhere to store and smooth each of the voltages V_a 904, V_c 908, V_d 910, V_e 914, V_g 918 and V_h 920.

[065] The circuit of FIGURE 9 may also be configured to produce negative voltages. V_h 920 may be connected to a positive source voltage V_{s+} , while V_g 918 and V_e 914 are connected to a reference (ground) voltage, to produce $-(V_{s+})$ at V_f 916. V_c 908 and V_a 904 may be connected to V_f 916. An output V_b 906 will be approximately $-2 \cdot V_{s+}$ if V_d 910 is connected to ground. If, instead, V_d 910 is connected to V_{s+} , then V_d 910 will be driven to approximately $-3 \cdot V_{s+}$. Capacitive storage, not shown, is assumed for each supply and intermediate voltage.

[066] In FIGURE 9, all of the p-switches 800 and all of the n-switches 830 may be controlled by a single phase of a clock, such as CLK 524 of FIGURE 5. Alternatively, a single phase of a first clock may control the switches connected to the fly capacitor 912 (*i.e.*, the switches of a charge pump section 922), while a single phase of a different second clock may control the switches connected to the fly capacitor 902 (*i.e.*, the switches of a charge pump section 924). If the clocks for charge pump sections 922 and 924 are inverted from one another, then the charge pump sections may be disposed in parallel to create a push-pull charge pump. That is, V_a 904 may be connected to V_e 914, V_b 906 to V_f 916, V_c 908 to V_g 918, and V_d 910 to V_h 920. Such a push-pull charge pump may, for example, provide lower ripple voltage and higher output current capabilities.

[067] Additionally, in circuits otherwise comporting with FIGURE 9, one or more passive switches (such as switches 704 or 706 in FIGURE 7) may replace switches in FIGURE 9 that are shown (in FIGURE 8) to be controlled by a charge pump clock output signal coupled to a control node of the switch. For example, the p-switch connected to V_g 918 and/or the n-switch connected to V_f 916 may be replaced by a passive switch, or by a diode. Similar substitutions may be made for the switches connected to V_c 908 and/or to V_b 906.

[068] Moreover, if V_d 910 and V_a 904 are equivalent to V_{in+} 402 and common reference 404 of FIGURE 5, then the left side of the transfer capacitor 902 may be coupled directly to a charge pump clock output such as 524, which would omit the left-side switches of the pump section 924 in FIGURE 9. The left-side switches of section 922 of FIGURE 9 may be omitted under analogous circumstances, with the left side of the transfer capacitor 912 coupled directly to a charge pump clock output instead. In such

a configuration, transfer capacitor charging current and discharging current may be limited not only by a drive signal (such as that on capacitor 522 in FIGURE 5) that has a limited dv/dt , but further or alternately by a current limiting device such as 512 or 518.

[069] FIGURE 10 is a simplified schematic diagram that illustrates generation of arbitrary
5 voltages by means of charge pump techniques. A source voltage V_{s+} 1002 may be used to derive an intermediate voltage, for example by means of resistors 1004 and 1006. Such intermediate voltage may optionally be buffered, if significant current output is desired, by means of buffer amplifier 1008, or may at least be connected to ground via a decoupling capacitor (not shown), to produce a projection voltage 1010 (with respect to common, or ground). The projection voltage 1010 may be regulated, for example
10 by means of feedback (not shown) applied to amplifier 1008. P-switches 800 and n-switches 830 may be employed in conjunction with a fly capacitor 1012, as shown. V_b may be an available voltage source (e.g., V_{s+}). Operation of the circuit will establish V_a 1014 at a voltage approximately equal to that of V_b 1017 plus the projection voltage 1010. The skilled person will readily see that rearrangement of the circuit will permit generation of arbitrary negative voltages with equal simplicity. Larger voltages may be
15 obtained by stacking charge pump circuits, in a manner as described with respect to FIGURE 9. Thus, arbitrary positive or negative voltages may be generated by means of charge pump circuits. All such charge pump circuits may be controlled by a single phase of a clock. Of course, the switches associated with different fly capacitors may alternatively use different clocks for control. Active switches may also be replaced with passive switches, for example in a manner as described with respect to FIGURE 7 or
20 FIGURE 9.

[070] Innumerable alternative embodiments of the charge pumps described above are possible. Any clock generator may be employed. It is desirable that the clock generator avoid introducing high di/dt noise on the supply, as can be achieved with many analog designs (for example, as shown in FIGURE 5) and some digital designs. It is desirable that dv/dt of the clock drive signals be limited, both
25 to help limit control node signal injection, and also to help limit (in conjunction with the transconductance of the relevant switch) the resulting di/dt of charging and discharging currents. It may be desirable to capacitively couple a charge pump clock to a control node of a transfer capacitor switch, for example in order to simplify control of control-node voltage levels. It may be desirable to utilize a single-phase clock output to control many, or all, of the transfer capacitor active switches within a charge pump, to minimize
30 circuit complexity. Any of these desirable features may be effected independently, or in combination with any of the other desirable features, or in combination with any other feature described herein. Thus, the skilled person may apply aspects of the method and apparatus described herein to a staggering variety of charge pump configurations.

Conclusion

[071] The foregoing description illustrates exemplary implementations, and novel features, of aspects of a charge pump method and apparatus for generating new voltages in circuits. The skilled person will understand that various omissions, substitutions, and changes in the form and details of the methods and apparatus illustrated may be made without departing from the scope of the invention. Numerous alternative implementations have been described, but it is impractical to list all embodiments explicitly. As such, each practical combination of apparatus and method alternatives that are set forth above or shown in the attached figures, and each practical combination of equivalents of such apparatus and method alternatives, constitutes a distinct alternative embodiment of the subject apparatus or methods. For example, a charge pump having a plural transfer capacitor (or 'stacked') architecture as shown in FIGURE 9, having at least one passive switch as shown in FIGURE 7, and having a settable voltage source as shown in FIGURE 10, constitutes an embodiment of the subject apparatus, as do all other such practical combinations of subfeatures. Therefore, the scope of the presented invention should be determined only by reference to the appended claims, and is not to be limited by features illustrated in the foregoing description except insofar as such limitation is recited in an appended claim.

[072] All variations coming within the meaning and range of equivalency of the various claim elements are embraced within the scope of the corresponding claim. Each claim set forth below is intended to encompass any system or method that differs only insubstantially from the literal language of such claim, as long as such system or method is not, in fact, an embodiment of the prior art. To this end, each described element in each claim should be construed as broadly as possible, and moreover should be understood to encompass any equivalent to such element insofar as possible without also encompassing the prior art.